



GENERAL INSTRUCTIONS for GLASS CLEANING

RULES TO FOLLOW :

- The transparency should be cleaned with care
- Ammonia cleaners are satisfactory to be used
- Use domestic household aqueous detergent solution (commonly available solvents) with clean rags or lint and dry using clean soft cloths
- Remove pasted impurities with steel wool 000 or glass/ceramic adapted (3M or equivalent)

RULES TO PROSCRIBE :

- Do not use highly alkaline and abrasive cleaning solutions
- Do not use scraper, razor blades, putty knives, etc.. to remove dirt
- Do not wipe the glass surface with dry or dirty rags
- Do not use abrasive cleaners others than those specified

This data sheet and information is the proprietary of SAINT GOBAIN SULLY.
Transmittal reproduction, dissemination and/or editing without authorization is prohibited